



## **How To Properly Bleed You New Power Rack & Pinion**

- 1) Fill your power steering reservoir with power steering fluid
- 2) Jack the front of the car high enough so the tires are off the ground
- 3) Turn the steering wheel back and forth from Lock to Lock at a slow steady pace about 25-50 times
- 4) Check fluid level and top off as needed
- 5) Start the engine and repeat steps 3 & 4 until all of the air is out of the system